

<http://www.broadern.co.kr>

MOFC CONTROL PLAN


2025.05.15

Broadband Wireless & Microwave Leading Company





Copyright © by BROADERN INC. All rights reserved.

1. MOFC BLOCKDIAGRAM





2.1 INDIVIDUAL MODE(1)



Individual Mode Option #1

- Accessing each of eight channels is individually configured by the master, **304** IO Pins are required.
- Need to reduce the I/O Pins.



2.1 INDIVIDUAL MODE(2)



Individual Mode Option #2

- If each of eight channels is individually configured by the master and set TF1(CH1~8) as a common, then I/O pin will be **234**.
- Still need to reduce the I/O Pins.



2.1 INDIVIDUAL MODE(3)



Individual Mode Option #3

- If each of eight channels is individually configured by the master and set TF1(CH1~8) as a **common1** & TF3(CH1~8) as a **common2**, then I/O pin will be required **164**.
- Satisfy with I/O Pin quantities.



3. COMMON QUAD MODE



Common Quad Mode

- The master fills configurations for channels 1 and 2. channel 1's configuration is used for Ch1 ~ 4 and channel 2's configuration is used for CH5 ~ 8.
- I/O Pins will be **184** Pins.

3. COMMON OCTAL MODE



Common OCTAL Mode

- The master configurations only channels 1. This configuration is then applied to CH1 ~8.
- I/O Pins will be **184** Pins.

4. Conclusion

- Due to lack of I/O Pins, Single Channel Mode(Each of the eight channels is individually configured by the master) is impossible to do it for now. However, if set TF1(CH1~8) as common1 and TF3(1~8) as common2, then I/O pin quantities are satisfied.
- Common Quad Mode and Common Octal Mode are able to access.